TOSAKA WIRELESS VACUUM CLEANER
INSTRUCTION MANUAL



CERTIFICATE

Grade : Qualified

Machine Assembler : Japan Technology

Production Code : TSK 0127 QUALIFIED

Product parameters

Productname	Wireless vacuum cleaner	Product model	
Workingvoltage	7. 4V	Rated power	120W
Chargingvoltage	8. 4V	Chargin current	0. 5A - 1A
Charge	About 3.5h	About 3.5h	2000 mah
Vacuum degree	8500pa	Dust collecting cup	600 ML

Please read this manual carfully before using the product and keep it properly



Intructions



1. Connect the charger to fully charge the battery
2. Connect the corresponding accessories according to the use situation (attached for installation and use)
3. Turn on the power switch or the vacuum cleaner to start working

Troubleshooting

Symptoms	Possible cause	Processing method
Product doet not work	Low battery	Charge the product
Suction weaking	Low battery	Charge the product
	Haipa filter screen is full of dust	Clean or replace the HEPA filter screen
	Air leakage of HEPA filter screen	Check whether the filter screen is installed correctly
	Hympa filter screen is wet	Air dried filter screen
The product cannot be charged	The adapter is not plugged in place	Check whether the adapter is plugged properly
	Insuffcient output current of adapter	Adapter output current must be greater than 1A